


USER



Instructions

Thule 3200
303002 - 303009





DE	Markise - Bedienungsanleitung
NL	Luifel - Gebruikershandleiding
FR	Store - Instructions d'utilisation
IT	Tenda - Istruzioni per l'uso
ES	Toldo - Instrucciones de uso
SV	Markis - Användarinstruktioner
FI	Markiisi - käyttöohjeet
DA	Markise - Brugervejledning
NO	Markise - Brukerinstruksjoner
PL	Markiza - instrukcje dla użytkownika





1 WARNINGS & INFO

Warnungen & Info / waarschuwingen & info / avertissements et informations / avvertimenti e informazioni


4

1 WARNINGS & INFO







AWNING




3 OPEN







4


A










B









5 ACCESSORIES



Blank lined paper for writing.



Thule NV, Kortrijkstraat 343 - BE 8930 Menen, BELGIUM



infoRV@thule.com



www.thule.com